



Installation Instructions CORE Pendant, Surface Mount Shallow Canopy

WARNING !

- Read all instructions before installing.
- Turn off power at main switch before installing or modifying the system.
- For installation by a qualified electrician.
- Luminaire is intended for installation in accordance with National Electric Code and local regulations. Consult with local inspector to assure compliance.
- Retain these instructions for future reference.

NOTE

- SUITABLE FOR DAMP LOCATIONS
CONVIENT AUX EMPLACEMENTS HUMIDES
- MIN 90°C SUPPLY CONDUCTORS
LES FILS D'ALIMENTATION DOIVENT CONVENIR POUR 90°C
- The canopy is designed to work with a standard round or octagonal junction box [1] (supplied and installed by others).

INSTALLATION

- Attach the cross bar [2] to the junction box (by others) [1] using two 8-32 screws [3].
- For CORE 200 or 300 with a remote LED driver:
 - Feed the low voltage wires from the fixture [6] up through the canopy [4] and the cross bar [2].
 - Connect the low voltage fixture wires to the output of the LED Driver (located remotely) using approved wire connectors as follows:
 - 1) LED V+: Red to Red
 - 2) LED V-: Black to Black
 - Connect the LED Driver AC input to the branch circuit wiring using approved wire connectors.
- For CORE 300 with a internal LED driver:
 - Feed the line voltage wires from the fixture [6] up through the canopy [4] and the cross bar [2].
 - Connect the fixture wires to the branch circuit wiring using approved wire connectors as follows:
 - 1) Line: Black to Black
 - 2) Neutral: White to White
 - 3) Ground: Green to Green. Bond to junction box as required.
- Screw the 1/4IP pipe nipple [5], located on top of the fixture [6] into the cross bar [2] until the bushing on the nipple is snug against canopy and the canopy is snug against the finished ceiling.

